

## Instruction of Solar Charge Controller

### User's Manual

12V/24V/48V 30A /40A /50A /60A

Dear Users:

Thank you for selecting our product. Please read this manual carefully before you use this product.

charging and discharging voltage automatically, improving the battery lifetime.

- Roundly reverse connected protection.
- Solar Panels, Battery, Solar Charge Controller positive poles are all connected together, adopting negative MOSFET in series control circuit.

### Important Safety Information

- It is better to install the controller in the room. If installed the controller outside, please keep the environment dry, avoid direct sunlight.
- The controller will be hot in process of working, please keep the environment ventilation, away from flammable.
- The open circuit voltage of solar panel is too high, (especially 24V and 48V system), please take care.
- The battery has acidic electrolysis, please put on goggles during installation. If you accidentally exposed to the electrolysis, please rinse with water.
- The battery has huge power, prohibit any conductor

|                                 |  |
|---------------------------------|--|
| Max. charge current             | 30A/40A/50A/60A  |
| Max. discharge current          | 30A/40A/50A/60A  |
| LVD                             | 11.0V ADJ 9V...12V ;x2 24V x4 48V  |
| LVR                             | 12.6V ADJ 11V...13.5V ;x2 24V x4 48V   |
| Float Voltage                   | 13.8V ADJ 13V...15V ;x2 24V x4 48V   |
| Boost charging                  | 14.4V ;x2 24V x4 48V Battery Voltage less than 12Vstart boost charging 2 hours |
| Battery Over Voltage Protection | 16.5V ; x2 24V x4 48V  |
| ReverseConnection Protection    | yes  |
| Load Over Current Protection    | Yes, each two minutes restart once   |
| Charge Type                     | PWM  |
| Temperature Compensation        | -24 mV/C for 12V system ;x2 24V x4 48V   |
| Working Temperature             | -20℃---+55℃  |
| Terminal Scale                  | 28—10 AWG  |
| Waterproof grade                | IP32   |
| Netweight                       | 650g   |

Subject to change without notice  
Version 201401

20

The controller is for off-grid solar system and control the charging and discharging of the battery. Main function is protecting battery. The intelligent charging process has been optimized for long battery life and improved system performance.

### Major Functions

The features are listed below:

- Automatic Identification System Voltage, 12V 24V 48V auto recognition
- Humanized LCD displaying and double button operation of man-machine interface.
- Completed technical data for setup and modify
- High efficiency intelligent PWM 3stage charging
- The load control mode can be selected, the timer function can be reset for street light at night.
- Reliable over voltage protection , short circuit protection , over load protection , overcharge protection , over-discharge protection.
- Accurate temperature compensation, correcting the

1

Full of quality vertical on solar panel, no solar symbol and no charge symbol on LCD

The solar panel connection open circuit, short circuit or reverse connected

Please check the cable of solar panels if they are correct connection and firmly.

The controller displaying LVD

The battery is over discharging

Please check the system design is reasonable or not if there is discharging capacity more than charging

The controller displaying HVD

The voltage of battery is high

Please first cut off the solar panel and see if the voltage get down normal level. If the fault do not finish, please cut off the battery with controller and reconnect again

The controller displaying Over Current Protection

The load is short circuit, or over load or high surge power

Please check the load cables have short circuit, the power of the load over rated design, the surge power of load too high.

### Technical Data

|                                   |             |
|-----------------------------------|-------------|
| Model                             |             |
| System Voltage                    | 12V/24V/48V |
| Max. Input Voltage of solar panel | 100V        |
| Self-consumption                  | ≤12mA       |

19

● **High Voltage Disconnection Protection (HVD)**

When the battery was charged to 13.8V, the PWM function will be started, the charge symbol will be flash, and the voltage of battery has been limited.

### Common Fault and Handling

| Fault Phenomenon                            | Possible Reason  | Solution   |
|---|--|--|
| LCD no display after connected with battery | <ul style="list-style-type: none"> <li>Battery Low</li> <li>Battery Reverse Connection</li> <li>The connection out of</li> </ul> | Please confirm the voltage of battery, reconnect the controller with battery firmly and correctly. |

18

short circuit the positive and negative pole of battery. Suggest to adding a fuse between battery and controller. (Slow motion type, the action current of the fuse should be 1.5 times rated current of controller.)

### The suggestion of using

- The controller could detect the temperature of environment to adjust the voltage of charging, so that the controller should be closed to battery as near as possible.
- Recommend system current density of cables less than 3A/mm<sup>2</sup>.
- Try to use multi strand copper wire in order to connecting with the terminal firmly. Loose power connection and/or corroded wires may result in resistive connections that melt wire insulation, burn surrounding materials or even cause fire.
- The battery should be full charged each month. Or the battery will be destroyed.

3

### The feature of LCD graphic symbol

- The default night display of controller: When the solar panel input voltage have been detected by controller less than sensor identification point voltage, this graphic symbol will be light.
- The default daytime display of controller: When the solar panel input voltage have been detected by controller more than sensor identification point voltage, this graphic symbol will be light.
- The indicator of PV array parameter: When the solar panels data was displaying, this graphic symbol will be light. For example the volage of solar panel.

4

come back or press "←" button force to unlock at main interface.

- Battery Over Voltage Disconnection (OVD)**

When the voltage of battery more than 16.5V, the over voltage protection will be started. The load cut off, at the same time the load and warning symbol flash. When the voltage of battery was decreased to 15V, the protection will be release. The output of the load is back (x 2.24V x 4.48V)

- Load Over Current Protection**

When the load is short circuit or overload, the output cut off, at the same time the load symbol and warning flash. Please confirm if there is short circuit on the load terminal, decrease the power of the load. 30s later the controller will be auto restart with unlock, or press "←" button force to unlock at main interface.

17

When battery voltage is more than 18V, the controller will beauto change to 24V system with 24V control data. When battery voltage is more than 36V, the controller will beauto change to 48V system with 48V control data. When battery voltage is less than 18V, the controller will be auto change to 12V system with 12V control data; When battery voltage is less than 36V, the controller will be auto change to 24V system with 24V control data.

If the system voltage is set to "1", the controller will be work under 12V version forever. The battery voltage is not valid. The reset data will be working after reconnection.

If the system voltage is set to "2", the controller will be work under 24V version forever. The battery voltage is not valid. The reset data will be working after reconnection.

### Protection Function

- Battery Low Voltage Protection(LVD)**

When the battery voltage less than 11V, the LVD protection started. The output cut off, at the same time the battery symbol and warning flash. Please increase charge current or increase charge time. When the battery voltage more than 12.6V, the protection will be closed. The load output is

16

- The indicator of battery parameter: When the battery parameter was displaying, this graphic symbol will be light. For example the volage of battery, temperature of battery.
- The indicator of load parameter: When the load parameter was displaying, this graphic symbol will be light.
- System Voltage: When the LCD shows different system voltage, the controller will adjust the technical data automatically.
- Numerical Display Area
- Timer Setting Function
- Switch Graphic Symbol.
- Unit Symbol Value
- Warning: When there is fault, this graphic symbol will be light.
- The indicator of Load status: Load on, Load off.
- The indicator of Output power: When the load terminal have output, this graphic symbol will be light.

5

- The indicator of capacity of battery: When the battery was in different capacity, the strip-type will show.
- The indicator of charge status: When the controller is charging, the symbol will be light, float charge will be flash, no charging no display.

### Installation Instructions

#### Controller Fixed

- The controller should be installed well-ventilated place, avoid direct sunlight, high temperature and do not install in location where water can enter the controller.
- Please select correct screw to fix the controller on the wall or other platform. Screw M4 or M5, Screw cap diameter less than 10mm.
- Please reserve enough space between the wall and controller, to allow for cooling and cable connection.
- The mounting holes distance is 155.8mm\*63mm, diameter of the hole is 5mm.

6

time set to ≤23H, it means the load start timer or sensor function. If the battery capacity is enough, the load will be started at sunset. The load will work under timer setting hours or stop working till sunrise.

**When the load join into timer or sensor mode, if the reset working time more than actual night time, the load output will be closed at sunrise, although the working time is not reach to setting hours. For example, the local actual night time is 10hours, user reset the working time at night is 12hours, but 10hours later the output will be closed automatically, the balance hours will be back to zero. The load will be working with next sunset signal.**

#### e) System Voltage Select

This parameter designed for customers wide range voltage requiring. The default display "UTO" system voltage 12/24V

System voltage select auto.

15

working. At the same time, the status of controller is in lock. Users have to charge the battery, when the battery voltage is higher than LVD Load disconnect voltage or press "←" button force to release. The load output will be back. The procedure is same with (a).

Above a. b. c three parameter default data was fully considered by designer according to the actual use. Generally users don't need to adjust. Please must be refer to battery supplier's suggestion, or the battery will be damaged or irreparable destroy.

#### d) Load Working Mode Selection

The control default load working 24hours. When the Load Working Time set to 24hours, the load will keep working 24hours in no fault status. When the load working

14

### Controller Connection

- All terminals are in tight status after factory, in order to well connected, please loose all terminals at first.
- The following order of connection please do not free change, or cause system voltage recognition fault.
- As figure, first connected the battery to controller correct poles. In order to avoid short circuit, please screw the cable of battery to the controller in advance, then connected to battery poles secondly. If your connection is correct, the LCD displaying will show battery voltage and other technical data. If LCD no indicate, please check the fault. The length of cable between battery and controller as shorter as possible. Suggest to 30CM-100CM.

7

- If short circuit happened on the terminals of controller, it will be result in fire or explode. Please be careful. (We strongly suggest to connecting a fuse at the battery side 1.5time of rated current of controller.)
- If the battery reverse connection, the output of controller also same with battery polarity, please do

8

"←" button ≥5S, the parameter on the interface will be flash, here is set up state. Loose the button, press "←" button again could operate plus data, press "←" button could operate minus data. After finish the needed technical data, long press "←" button again ≥5S, the parameter save and come out set up state. If 20s no any operation, automatically back to main interface.

#### b) Low Voltage Reconnection Voltage (LVR)

When the voltage of battery is low, the control will stop offer power to the load. If the controller needs reconnected the output, the Load reconnect voltage of battery must be higher than LVD voltage or press "←" button force to release. The procedure is same with (a).

#### c) Low Voltage Disconnection Voltage

When the voltage of battery is low, the load output will be cut off. When the controller detected the battery voltage was less than LVD point, the cut off function will be immediately

13

#### a) Float Voltage Set up

This parameter is High Voltage Disconnection (HVD) voltage. (Boost state voltage) will be increase 0.6V base on HVD). The controller will be started PWM function at this point(HVD), limited voltage rising. Press "←" join in float voltage menu. Long press

12

not connect any load with controller at that time, or the load and controller will be destroyed.

- As figure, connected solar panels with controller correctly, if the connection is successful and sunshine is full, the LCD will show solar panel and an arrow from solar panel to battery will be light.

The voltage of solar panel is very high under sunshine, high voltage can cause injury or destroy controller. As figure, connected loads with controller correctly. In order to avoiding injury from load voltage, please close to the output of controller with button at first, then connected the load on the controller. The controller do not offer reverse connection protection for load, so please take care, reverse connection for load will be destroy bulb.

- About ground connection of solar system

Please noted, this solar charge controller designed by all positive connection, all components inside the controller are

9

positive combined together. If your solar system needs ground connection, please let positive ground connection.

**Warning: For some force to ground connected system, such as solar communication system, portable solar system, they are negative ground connected, at this time please do not positive connected, or can cause short circuit.**

### Operation and Indication

#### Main interface

- The controller will have 1s initialization interface after electrified, then go into main interface.

- If no operation at main interface inner 20s, the main interface will be auto exchange during voltage of battery, volage of solar panel, temperature of environment each interface keep 3s. Long press

10

"←" more than 5s at main interface, it will speed auto exchange. Loose button will stop speed.

- Press "←" under main interface could open or close the load output.

- Press "←" button could join into next menu under main interface

11